



**ARA Instruments**

90 Hillview 1, Eugene, OR 97408 USA

T: 541.844.1686 F: 541.344.8870

E: [sales@arainstruments.com](mailto:sales@arainstruments.com)

W: [www.arainstruments.com](http://www.arainstruments.com)

## Firmware update instructions for ARA N-FRM and LFR Samplers

**Step 1)** Extract files from zipped folder. Move all 4 individual files (FW\_ASB, FW\_ASB12, FW\_ASB15, FW\_ASB22) to the USB drive. The files must be in the main directory on the USB drive and files cannot be in a folder.

**Step 2)** Turn on sampler, go to **SETUP > UPDATE FIRMWARE** and follow prompts on the screen.

**Step 3)** Once Firmware update has completed, go to **SETUP > SYSTEM SETUP > REBOOT**